	\checkmark	Name of document	Document ID VX-VS-079 Rv 3
See.	GOOD. CLEAN. FUN.	Planned Maintenance - VX-1	Always check the latest revision before use – uncontrolled in printed format
			Date of issue:
			9-Feb-09
Prepared			Approved
J. Twombly			C. Sistopaoli

General

In order to keep valid the warranty, the service should be done every 6 months from the date of purchase. No mileage limitation.

There's a tolerance of \pm 30 days that the service must be performed.

Please refer to the service manual http://www.vectrixservice.com for

Work Order Codes referenced in this document.

Planned Maintenance (6, 12, 18 months)

Diagnostic Software:

- 1. Software Upgrade if available (reference WOC: S-ST-000020)
- 2. Perform a memory dump .
 - 2a On "Memory" page in the diagnostic software do a Memory Dump with Address=0 and Size=0x800
 - 2b Save to a file with the last 4 digits of the VIN and the date. Example: 2018-9Feb09.csv
 - 2c Send to your TSO representative.

er 4	About						
[Memory Dump						
	Address:	0					
	Size:	0x800					
		Start					
L							
	Write	Read					
		1					

Mechanical:

- 1. Fans (Plenum, Motor Controller and Charger) check plug in and check if functioning
- 2. Throttle box check & eventual cleaning / lubrication with oil only (reference WOC: S-RW-S00077)
- 3. Lighting check check for functioning> running light, hi / low fron beam, directionals right / left and front / rear, license plate light
- 4. Trunk seat switch and kickstand switch check functioning
- 5. Brake pads and brake fluid level check (reference WOC: S-RW-S00033 rear & S-RW-S00037)
- 6. Brake caliper check & tightening torque (reference WOC: S-RW-S00033 rear & S-RW-S00037)
- 7. Brake disc screws visual inspection (NO TOOLS).

		Name of document	Document ID
See.	GOOD. CLEAN. FUN.	Planned Maintenance - VX-1	VX-VS-079 Rv 3 Always check the latest revision before use – uncontrolled in printed format
			Date of issue:
			9-Feb-09
Prepared			Approved
J. Twombly			C. Sistopaoli

- 8. Side stand tightening torque check, cleaning, and lubrication with spray lithium grease (reference WOC: S-XC-S00007 Installation step 2.)
- 9. Windshield (reference: WOC: S-XC-S00286 Installation step 4.) and front subframe tightening check (reference: WOC: S-XC-S00045)
- 10. Tire pressure check (reference owner's manual)
- 11. Check for oil leakage from gearbox. (reference WOC: S-RW-S00294)

Each maintenance visit will take approximately 45 minutes. Service to be paid by the customer.

All the repairs performed after the checks must be reported in WCFs and charged to the customer or claimed to Vectrix as warranty.